OLIGHT

USER MANUAL



SPECIFICATIONS

TURBO	1700lm	1700cd
HIGH	700lm	700cd
MED	180lm	180cd
LOW	30lm	30cd
MOON	1lm	1cd

TURBO	HIGH	MED	LOW	MOON
2200m	1170m	577m	236m	36m

1.5w	12.3000mA	IP68
1.65~1865.98lm	320g/11.3oz	
0.01~1700cd	88.5mm*25.4mm	

*** All above specifications are test results based on ANSI/NEMA FL1-2009 Standard. The tests are performed using the battery included in the flashlight.***

AVAILABLE BATTERIES

- 1 x customized 3500mAh 18650 rechargeable lithium battery

BATTERY LEVEL INDICATOR

> 60%	< 5%
Green Indicator	Indicator Blinks Red

10~60%	5~10%
Orange Indicator	Red Indicator

NOTE: If using moonlight mode, the battery indicator will only display when the battery level is below 5%.

WARRIOR Mini 2
available at BrightGuy

Thank you for purchasing this Olight Product. Please read this manual carefully before use and keep it for future reference!

BATTERY INSTALLATION

Before first use, please unscrew the body and remove the insulating film. If the battery needs to be replaced, make sure that the positive end of the new battery faces the flashlight head when you put it in.

USB MAGNETIC CHARGING CABLE — MCC3

Parameter	Specification
Charging cable	USB type-A - magnetic charging connector, length: 0.5m
Input	USB-A: 5Vdc DC 3A
Charging pattern	CC&CV
Maximum charging current	1.5A
Voltage at fully charged	4.2V ± 0.05V
Time to fully charge	2.5 hours (for reference only. When the USB power source is insufficient or the MCC3 is charging a device with a large capacity battery at the same time, it will take longer to charge.)
Charge indication	Red: charging Green: charging complete or MCC3 is disconnected with flashlight

CHARGING

ATTENTION

1- Please keep the surface of the lens clean. Stains or water mist will affect the performance of the built-in sensor located in the black area, resulting in the failure of light or false alerts, please erase in time.

2- Pay attention to protect the lens from scratches. Scratches on the surface of the lens will reduce the luminous flux in severe cases, it will affect the internal sensor performance, resulting in the failure of high and above modes.



DANGER

• DO NOT throw the light directly into human eyes. This may cause serious injury.

• The max load of the Carabiner-Style Ring is 5kg, and please DO NOT use it for climbing.



NOTICE

• When the flashlight is turned off, moonlight, low, medium, or high mode will be memorized and become the default mode when the light is turned on again (high mode will only be memorized for 10 minutes. After that, the memorized mode will revert to the medium setting).

• The turbo mode will slowly step down to high mode in 4 minutes in normal temperature.

• DO NOT short-circuit the tail switch cap with the surrounding ring. A short circuit in this case will result in a weak electric discharge between them and may lead to a malfunction (it may flash 3 or 4 times) of the light.

• The magnetic tail is easy to attract iron debris. Please keep the tail switch cap and the ring surrounding it clean.

• **NOTICE:** The lanyard clip can only be installed in the rear clip slot as shown below.

WARNING

• DO NOT activate turbo mode repeatedly under high temperature to prevent the flashlight body from overheating and hurting the user's hand.

• The tail switch may not work while immersed in sea water or other conductive media. Please try to keep it clean and dry.

• DO NOT use Non-protected rechargeable batteries.

• DO NOT use the battery if the wrapper is broken, or it may cause damage to the flashlight.

• Take good care of the battery, if the battery needs to be replaced, please keep the removed battery in a safe place. DO NOT let it in the conductive metals.

• If the product is left unused or carried and transported, please lock the button to avoid accidentally activating the flashlight.

EXCLUSION CLAUSE

Olight is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual, including but not limited to using the product inconsistent with the recommended lockout mode.

PROXIMITY PROTECTION FUNCTION

When the front lens proximity sensor detects an obstruction nearby, the brightness will automatically reduce. While in this state, the side switch can only turn the light off. The light will turn off directly if the blockage continues for more than 60 seconds.

EXCLUSION CLAUSE

Olight is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual, including but not limited to using the product inconsistent with the recommended lockout mode.

DANGER

• DO NOT throw the light directly into human eyes. This may cause serious injury.

• The max load of the Carabiner-Style Ring is 5kg, and please DO NOT use it for climbing.

NOTICE

• When the flashlight is turned off, moonlight, low, medium, or high mode will be memorized and become the default mode when the light is turned on again (high mode will only be memorized for 10 minutes. After that, the memorized mode will revert to the medium setting).

• The turbo mode will slowly step down to high mode in 4 minutes in normal temperature.

• DO NOT short-circuit the tail switch cap with the surrounding ring. A short circuit in this case will result in a weak electric discharge between them and may lead to a malfunction (it may flash 3 or 4 times) of the light.

• The magnetic tail is easy to attract iron debris. Please keep the tail switch cap and the ring surrounding it clean.

• **NOTICE:** The lanyard clip can only be installed in the rear clip slot as shown below.

WARNING

• DO NOT activate turbo mode repeatedly under high temperature to prevent the flashlight body from overheating and hurting the user's hand.

• The tail switch may not work while immersed in sea water or other conductive media. Please try to keep it clean and dry.

• DO NOT use Non-protected rechargeable batteries.

• DO NOT use the battery if the wrapper is broken, or it may cause damage to the flashlight.

• Take good care of the battery, if the battery needs to be replaced, please keep the removed battery in a safe place. DO NOT let it in the conductive metals.

• If the product is left unused or carried and transported, please lock the button to avoid accidentally activating the flashlight.

EXCLUSION CLAUSE

Olight is not liable for damages or injuries sustained resulting from the usage of the product inconsistent with the warnings in the manual, including but not limited to using the product inconsistent with the recommended lockout mode.

DANGER

• DO NOT throw the light directly into human eyes. This may cause serious injury.

• The max load of the Carabiner-Style Ring is 5kg, and please DO NOT use it for climbing.

CONTENTS

(EN) English 01
(CHS) 简体中文 02
(FI) Finnish 03
(NO) Norwegian 04
(SV) Swedish 05
(NED) Nederland 07
(PL) Polska 08
(DE) Deutsch 10
(HU) Magyarország 11
(RU) Русский 13
(ES) Español 14
(RO) Romanesc 16
(UA) Ukrainian 17
(JP) 日本語 18
(TH) ไทย 20
(FR) Français 21
(BG) български 23
(IT) Italia 24
(SK) Slovenskýjazyk 26

HOW TO OPERATE

SIDE SWITCH

ON/OFF: Single click the side switch to turn the light ON/OFF. When the light is turned on again, it will return to the previously memorized mode.

CHANGE BRIGHTNESS LEVEL: When the flashlight is on, press and hold the side switch and it will, starting from the present brightness level, automatically cycle through Low, Medium, and High mode. The mode is selected when the side switch has been released. (To have extra moonlight and turbo are not in the automatic cycle.)

MOONLIGHT MODE: When the flashlight is off, press and hold the side switch for over one second to access the moonlight mode. If the memorized mode is moonlight, simply click the switch to access it.

TURBO: Press the side switch past the detent (or click twice from On) to enter turbo, double-click again to return. If the memorized mode is Turbo, Turbo will be activated directly.

STROBE: Quickly triple click the side switch to enter the strobe mode. To exit this mode, single click or press and hold the side switch.

LOCKOUT/UNLOCK: When the flashlight is off, press and hold the side switch (for about 2 seconds) to access the button lockout mode (the flashlight will enter the moonlight mode first and will then switch off to signal the lockout mode). Under the lockout mode, press and hold the side switch for less than 1 second, the flashlight will flash 3 times to signal that it is unlocked. To switch it, keep holding the side switch for over one second until the moonlight mode is on again.

TAIL SWITCH

The flashlight produces different output settings by pressing lightly and then the tail switch (please refer to the following program configurations).

TWO DIFFERENT PROGRAM CONFIGURATIONS

CONFIGURATION 1 (FACTORY DEFAULT SETTING): Half press for Medium, hard press for Turbo.

Single press the tail switch (press and release quickly) to turn the flashlight on or off.

Press and hold the tail switch for momentary on. Release to turn off.

CONFIGURATION2: Half press for Turbo, hard press for Strobe. Intensive pressing to activate Beacon.

SWITCH BETWEEN DIFFERENT PROGRAM CONFIGURATIONS

Switch between configuration 1 and configuration 2 by pressing hard then holding tail switch and under press on side switch at the same time; when you release tail switch, the Configuration will be selected.

操作说明

侧按键

开/关机： 单按开、关机。开机时，手电将会调用关机前的亮度模式。

调节亮度： 通过按键可调整亮度，长按开启手电，手电将从低亮度开始，依次经过低/中/高/超强四个亮度档位循环。松开按键，手电将保持在当前亮度。

超亮模式： 手电处于关闭状态下，长按开启手电，手电将从低亮度开始，依次经过低/中/高/超强/月光五个亮度档位循环。松开按键，手电将保持在当前亮度。

月光模式： 手电处于关闭状态下，长按开启手电，手电将从低亮度开始，依次经过低/中/高/超强/月光五个亮度档位循环。松开按键，手电将保持在当前亮度。

爆闪： 快速按键三下（或已经上调入强、使用状态按键两键后操作）。

锁定/解锁： 关机状态下，长按按键（约2秒）直至听到月光模式，手电进入锁键状态，月光模式闪烁3下。锁定状态下，短按一下，手电将闪烁3下以示解锁。

记忆： 手电关闭后，手电将记忆关机前的亮度模式。

尾按键

尾按键直接按压可切换不同的亮度档位（详见下列不同手电亮度档位设置）。

不同手电亮度档位设置

设置1（出厂默认设置）： 半按开启中亮，用力按开启强亮。

单击尾按键开启手电，再次单击关闭手电。

长按尾按键开启手电，松开尾按键关闭手电。

设置2： 半按开启强亮，用力按开启爆闪。

使用说明

侧按键

开/关机： 单按开、关机。开机时，手电将会调用关机前的亮度模式。

调节亮度： 通过按键可调整亮度，长按开启手电，手电将从低亮度开始，依次经过低/中/高/超强四个亮度档位循环。松开按键，手电将保持在当前亮度。

超亮模式： 手电处于关闭状态下，长按开启手电，手电将从低亮度开始，依次经过低/中/高/超强/月光五个亮度档位循环。松开按键，手电将保持在当前亮度。

爆闪： 快速按键三下（或已经上调入强、使用状态按键两键后操作）。

锁定/解锁： 关机状态下，长按按键（约2秒）直至听到月光模式，手电进入锁键状态，月光模式闪烁3下。锁定状态下，短按一下，手电将闪烁3下以示解锁。

记忆： 手电关闭后，手电将记忆关机前的亮度模式。

尾按键

尾按键直接按压可切换不同的亮度档位（详见下列不同手电亮度档位设置）。

不同手电亮度档位设置

设置1（出厂默认设置）： 半按开启中亮，用力按开启强亮。

单击尾按键开启手电，再次单击关闭手电。

长按尾按键开启手电，松开尾按键关闭手电。

设置2： 半按开启强亮，用力按开启爆闪。

使用方法