IMPORTANT: FULLY CHARGE BEFORE FIRST LISE

Thank you for selecting the Wedge® XT, a truly remarkable EDC light. As with any professional tool, reasonable care and maintenance of this product will provide years of dependable service. Please read this manual before using the Wedge® XT. It contains important safety and operating instructions and should be saved.

SAVE THESE INSTRUCTIONS. This guide contains important safety and operating instructions for your Wedge® XI

A. Fire and burn hazard. The Wedge® XT provides a powerful beam. When operated for more A WARNING surface, including skin, while in operation. Transport or store the Wedge® XT with its face against any can accidentally be turned on. The resultant heat build-up can cause a fire, burns or damage to the flashlight.

BATTERY SAFETY

XPLOSION RISK, BURN, AND FIRE HAZARD, DO NOT DISASSEMBLE, CRUSH, SHORT CIRCUIT, HEAT ABOVE 140°F (60°C), OR DISCARD IN FIRE, USE ONLY WITH THE SPECIFIED STREAMLIGHT ACAUTION PRODUCTS. KEEP AWAY FROM CHILDREN. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY

I FD SAFFTY

) RADIATION (RG-2). DO NOT STARE INTO BEAM. MAY BE HARMFUL TO A CAUTION EYES. PEB IEC 62471 Ed 1.0:2006-07.



Charge before first use.

The rechargeable battery contained in this product is recyclable. At the end of its useful life, under various country and state laws, it may be illegal to dispose of this battery in the municipal solid waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal (In USA: RBRC).

To charge the light, first confirm that the charge port is free from debris. Plug the USB end of the cord into a power source, then plug the USB-C connector into the port on the side of the light. The charge indicator is located above the charge port and will glow red for charging and green for charge completion. The light may remain plugged into the USB-C charge port after charging is completed.

The battery indicator is located above the charge port. The indicator will illuminate when the light is first turned on to display the battery level. Green will illuminate for 5 seconds to show the battery has sufficient power. Steady red indicates the battery needs to be charged soon. The light will become dimmer before the battery shuts down.

Using SL #22058 charge cube, product recharges in 5 hours. Using a non-Streamlight charge cube is permitted with a minimum supply current of 300mA.

CHARGE CORD SAFETY

 Do not abuse the cord. Replace damaged cords or plugs immediately. Remove light from charge before attempting any routine cleaning or maintenance. . Do not try to repair the unit or cord yourself. Take it to a gualified service facility or return it to the

factory. USING THE LIGHT

The on/off switch is located on the end of the light. Press and release to turn the light on or off. Press and hold for momentary operation. When released, the light will turn off. . Double tap the switch within 0.4 seconds to toggle between high mode (default) and low

mode. Lockout Function

The Wedge[®] XT features a Five-Tap[™] programmable switch allowing the user to lock out the switch from unintentional use. To enable the lockout feature, press the switch rapidly 4 times (within 0.8 seconds per press) and hold it down the 5th time. Continue holding the switch until the light blinks (approximately 1 second), then release the switch. The Wedge® XT will not turn on when the switch is pressed and released, however a small light above the charge port will indicate that the lockout feature is enabled.

To disable the lockout feature, repeat the Five-Tap™ procedure by pressing the switch rapidly 4 times (within 0.8 seconds per press) and holding it down the 5th time. The light will blink to indicate that the lockout feature is disabled.

Accessing Other Programs

The Wedge® XT features a TEN-TAP® programmable switch, allowing the user to select one of two different programs. To change to the next program, starting from the "Off" position, press the switch rapidly 9 times (within 0.8 seconds per press) and hold it down the 10th time. Continue holding the switch until the light blinks (approximately 1 second), then release the switch.

· Available programs are High-Low (Factory Default), or Low-

High. MAINTENANCE

Regularly check that the charge port is free from debris. To extend the life of the battery, fully charge before storage.

PRODUCT USE

Streamlight flashlights are intended for use as high intensity, heavy duty, and portable light sources. Use of Streamlight flashlights for any purpose other than as light sources is specifically discouraged by the manufacturer Streamlight specifically disclaims liability for other than recommended use.

Be sure to use only genuine Streamlight replacement parts to ensure product safety. Substitution may invalidate the product approval. Do not try to repair the unit yourself. Send to a qualified service facility or return it to the factory.

Streamlight Limited Lifetime Warranty

Streamlight warrants this product to be free of defects for a lifetime of use except for batteries and bulbs, abuse and normal wear. We will repair, replace, or refund the purchase price of this product should we determine it to be defective. This limited lifetime warranty also excludes rechargeable batteries, chargers, switches, and electronics which have a 2-year warranty with proof of purchase. THIS IS THE ONLY WARRANTY, EXPRESSED OR IMPLIED. INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARE EXPRESSLY DISCLAIMED EXCEPT WHERE SUCH LIMITATION IS PROHIBITED BY LAW. You may have other specific legal rights which vary by jurisdiction.

Go to www.streamlight.com/support for a complete copy of the warranty. To register your product, go to www.streamlight.com (Online Product Registration). Retain your receipt or any proof of purchase.

SERVICE OPTIONS

The Wedge® XT contains few or no user-serviceable parts

For service options, go to www.streamlight.com/support/service and complete the Online Service Request for factory service or to find the location of an authorized Streamlight repair center near you.

Or contact:

Customer Service STREAMLIGHT, INC 30 Eagleville Road Suite 100 Eagleville, PA U.S.A. 19403-39996 Phone: (800) 523-7488 Toll-Free or 610-631-0600 Fax: (800) 220-7007 or 610-631-0712

STREMUIGHT Operating Instructions Instrucciones de funcionamiento WEDGE[®] XT Instructions d'utilisation Bedienungsanleitung Caution: LED Badiation (BG-2) -Attention : Rayonnement LED (RG-2) -Ne pas regarder dans le faisceau. Do not stare into beam May be harmful to eyes. Susceptible d'endommager les yeux. IMPORTANT: FULLY CHARGE BEFORE FIRST USE. IMPORTANT : CHARGER COMPLÈTEMENT AVANT LA PREMIÈRE UTILISATION. Precaución: Badiación de LED (BG-2) -Achtung: LED-Strahlung (RG-2) -No mire directamente al haz Nicht direkt in den Lichtstrahl schauen. Podría dañar su vista Augenschädigung möglich. IMPORTANTE: CÁRGUELA COMPLETAMENTE WICHTIG: VOB DEM EBSTEN ANTES DE USABLA POB PRIMERA VEZ. GEBRAUCH VOLL AUFLADEN.

CE CK BC

FU Authorized Representative: Falcon Logistics B.V. Hoeksteen 26 F. 2132 MS Hoofddorp, Netherlands For compliance information, please visit www.streamlight.com/compliance